



RADIO AND PLAYER (w/ WOOFER SPEAKER)





RADIO AND PLAYER (w/ WOOFER SPEAKER)

SERVICE HINTS

S11 STEREO COMPONENT AMPLIFIER

- 10-GROUND : ALWAYS APPROX. 12 VOLTS
- 9-GROUND : ALWAYS CONTINUITY
- 1-GROUND : APPROX. 12 VOLTS WITH IGNITION SW AT ON OR ACC POSITION

○ : PARTS LOCATION

| CODE | SEE PAGE | CODE | SEE PAGE | CODE | SEE PAGE |
|------|----------|------|----------|------|----------|
| F15 | 27 | R 1 | 26 | R24 | 27 |
| F16 | 27 | R11 | 27 | R25 | 27 |
| F18 | 27 | R12 | 27 | S10 | 27 |
| F18 | 27 | R15 | 27 | S11 | 27 |
| J 1 | 26 | R16 | 27 | S14 | 27 |

○ : RELAY BLOCKS

| CODE | SEE PAGE | RELAY BLOCKS (RELAY BLOCK LOCATION) |
|------|----------|---|
| 1 | 20 | R/B NO. 1 (LEFT KICK PANEL) |
| 5 | 21 | R/B NO. 5 (FRONT LUGGAGE COMPARTMENT RIGHT) |

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| CODE | SEE PAGE | JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION) |
|------|----------|--|
| 3A | 22 | COWL WIRE AND J/B NO. 3 (BEHIND COMBINATION METER) |
| 3C | | |
| 3D | | |

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| CODE | SEE PAGE | JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION) |
|------|----------|--|
| IE4 | 32 | ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL) |
| IF1 | 32 | COWL WIRE AND FRONT DOOR LH WIRE (LEFT KICK PANEL) |
| IJ3 | 34 | COWL WIRE AND LUGGAGE ROOM WIRE (RIGHT KICK PANEL) |
| IJ1 | 34 | COWL WIRE AND FRONT DOOR RH WIRE (RIGHT KICK PANEL) |

▽ : GROUND POINTS

| CODE | SEE PAGE | GROUND POINTS LOCATION |
|------|----------|------------------------|
| IB | 32 | LEFT KICK PANEL |

○ : SPLICE POINTS

| CODE | SEE PAGE | WIRE HARNESS WITH SPLICE POINTS | CODE | SEE PAGE | WIRE HARNESS WITH SPLICE POINTS |
|------|----------|---------------------------------|------|----------|---------------------------------|
| I 8 | 34 | COWL WIRE | B18 | 36 | FRONT DOOR RH WIRE |
| I10 | | | B21 | 36 | COWL WIRE |
| I11 | | | B22 | | |
| B15 | 36 | FRONT DOOR LH WIRE | | | |


F15, F16 GRAY




F17, F18




J 1




R 1



R11, R12, R16, R25




R15, R24



S10 ORANGE



S11 BLUE



S14

