

EMISSION CONTROL SYSTEMS

SYSTEM PURPOSE

EG06T-02

| System | Abbreviation | Purpose |
|--|------------------------------------|--|
| Positive crankcase ventilation Fuel evaporative emission control Exhaust gas recirculation Three-way catalyst Electronic fuel injection* | PCV EVAP EG R TWC SMPI | Reduces blow-by gas (HC) Reduces evaporative HC Reduces NOx Reduces HC, CO and NOx Regulates all engine conditions for reduction of exhaust emissions. |


* For inspection and repair of the SMPI system, refer to SMPI Section.

V00997

PREPARATION

RECOMMENDED TOOLS

EG06V-01

| | | |
|---|--------------------------------------|--|
|  | 09082-00015 TOYOTA Electrical Tester | |
|---|--------------------------------------|--|

EG06W-02

EQUIPMENT

| | |
|---------------|-----|
| Heater | TVS |
| Thermometer | TVS |
| Tachometer | |
| Torque wrench | |
| Vacuum gauge | |

EG06X-02

SSM (SPECIAL SERVICE MATERIALS)

| | |
|---|-----|
| 08833-00070 Adhesive 1324, THREE BOND 1324 or equivalent | TVS |
|---|-----|