

E INDEX

INDEX----- E - 1
RHD VEHICLE----- E - 1
LHD VEHICLE ----- E - 4

1 INDEX

1-1 RHD VEHICLE

	ITEM	PAGE	ITEM	PAGE		
A	A/C evap. temp. sensor	D-241	Data link connector(Immobilizer)	D-109	D	
	A/C switch	D-241	Data link connector(Meter)	D-141		
	A/T ECU(A/T)	D-69	Defogger	D-125		
	A/T ECU(ABS)	D-62	Defogger switch	D-125		
	A/T ECU(Back up lamp)	D-189	Dome lamp	D-93		
	A/T ECU(Engine)[K3-VE engine]	D-44	Doorlock motor	D-101		
	A/T ECU(Meter)	D-141	Doorlock switch	D-102		
	ABS ECU(A/T)	D-70	Dual pressure switch	D-241		
	ABS ECU(ABS)	D-61	Duty solenoid	D-69		
	ABS ECU(Back up lamp)	D-189	EFI ECU(A/T)	D-70		E
	ABS ECU(Engine)[1KR-FE engine]	D-32	EFI ECU(ABS)	D-62		
	ABS ECU(Engine)[K3-VE engine]	D-44	EFI ECU(Back up lamp)	D-189		
	ABS ECU(Meter)	D-141	EFI ECU(Engine)[1KR-FE engine]	D-29		
	Airbag ECU	D-85	EFI ECU(Engine)[K3-VE engine]	D-41		
	Airbag squib	D-85	EFI ECU(Meter)	D-141		
	Alternator	D-21	EFI main relay(1KR-FE engine)	D-30		
ANT	D-221	EFI main relay(K3-VE engine)	D-42			
Antenna coil	D-109	EPS ECU	D-77			
B	Back-up lamp	D-189	Flasher relay	D-165	F	
	Back-up lamp switch	D-189	Floor console illumination	D-181		
	Brake vacuum pressure switch	D-44	Fog lamp relay	D-158		
C	Cam position sensor(1KR-FE engine)	D-30	Fog lamp switch	D-157		
	Cam position sensor(K3-VE engine)	D-42	Front fog lamp	D-158		
	Cigarette lighter or Power outlet	D-237	Front oxygen sensor(1KR-FE engine)	D-30		
	Clearance lamp	D-181	Front oxygen sensor(K3-VE engine)	D-42		
	Courtesy switch	D-102	Front passenger seat belt warning	D-142		
	Crank angle sensor(1KR-FE engine)	D-30	Front satellite sensor	D-85		
	Crank angle sensor(K3-VE engine)	D-42	Front speaker	D-221		
	Curtain shield airbag	D-86	Front speed sensor	D-61		
D	Data link connector(A/T)	D-69	Front turn lamp	D-165		
	Data link connector(ABS)	D-61	Front washer motor	D-197		
	Data link connector(Airbag)	D-85	Front wiper motor	D-197		
	Data link connector(Back up lamp)	D-189	Front wiper switch	D-197		
	Data link connector(DLC)	D-249	Fuel pump motor(1KR-FE engine)	D-30		
	Data link connector(Engine)[1KR-FE engine]	D-31	Fuel pump motor(K3-VE engine)	D-42		
	Data link connector(Engine)[K3-VE engine]	D-43	Fuel pump relay(1KR-FE engine)	D-30		
	Data link connector(EPS)	D-77	Fuel pump relay(K3-VE engine)	D-42		

	ITEM	PAGE	ITEM	PAGE	
F	Fuel sender gauge	D-141	Manifold absolute pressure/intake air temperature integrated type sensor	D-31	M
H	Hazard switch	D-165			
	Headlamp	D-149	Map lamp	D-93	
	Headlamp leveling switch(Headlamp)	D-150	Master switch	D-133	
	Headlamp leveling switch (Tail & License plate lamp)	D-182	ABS	D-62	
	Headlamp leveling unit	D-150	Airbag	D-86	
	Headlamp relay	D-149	Brake	D-142	
	Headlamp switch	D-149	Buzzer(Back up lamp)	D-189	
	Heater blower motor	D-242	Buzzer(Meter)	D-141	
	Heater blower switch	D-242	Buzzer(Tail & License plate lamp)	D-182	
	Heater relay	D-241	Charge	D-21	
	Heater resistor	D-242	Door	D-102	
	High mounted stop lamp	D-173	Driver's seat belt	D-142	
	Horn	D-229	EPS	D-77	
	Horn relay	D-229	High beam	D-150	
	Horn switch	D-229	High-water temperature	D-142	
I	IG relay	D-3	Illumination	D-182	
	Ignition coil(1KR-FE engine)	D-29	LCD(A/T)	D-70	
	Ignition coil(K3-VE engine)	D-41	LCD(Back up lamp)	D-189	
	Ignition switch	D-2	LCD(Meter)	D-141	
	Immobilizer ECU	D-109	Low-water temperature	D-142	
	Injector(1KR-FE engine)	D-30	MIL(1KR-FE engine)	D-32	
	Injector(K3-VE engine)	D-43	MIL(K3-VE engine)	D-44	
	Intake air temp. sensor	D-43	O/D OFF	D-70	
	ITC ECU	D-101	Oil	D-142	
K	Key switch	D-141	Rear fog	D-157	
	Keyless entry sensor	D-101	Security	D-109	
	Knock sensor(1KR-FE engine)	D-30	SPEED	D-141	
	Knock sensor(K3-VE engine)	D-42	Turn	D-165	
L	License plate lamp	D-181	MGC relay	D-241	
	Linear throttle sensor(1KR-FE engine)	D-30	Mirror adjust	D-117	
	Linear throttle sensor(K3-VE engine)	D-43	Motor	D-77	
	LUC solenoid	D-69	Neutral start switch(A/T)	D-69	N
	Luggage room lamp	D-93	Neutral start switch(Back up lamp)	D-189	
M	Magnet clutch	D-241	Noise filter(1KR-FE engine)	D-29	
			Noise filter(K3-VE engine)	D-42	
			O/D OFF switch	D-69	O

	ITEM	PAGE	ITEM	PAGE	
O	Oil control valve(1KR-FE engine)	D-31	Starter	D-13	S
	Oil control valve(K3-VE engine)	D-43	Starter relay	D-13	
	Oil fluid level switch	D-142	Stepper motor for ISC	D-31	
	Oil pressure switch	D-142	Stepper motor type EGR valve	D-31	
	Oil temperature sensor	D-69	Stop lamp	D-173	
	Output revolution sensor	D-70	Stop lamp switch	D-173	
P	Parking breke switch	D-142	Switch solenoid	D-69	T
	Power window motor	D-133	Tachometer	D-141	
	Power window switch	D-133	Tail lamp	D-181	
	Pressure sensor	D-43	Tail lamp switch	D-181	
	Pretensioner	D-85	Torque sensor	D-77	
	Purge VSV(1KR-FE engine)	D-30	Turbine revolution sensor	D-70	
R	Purge VSV(K3-VE engine)	D-43	Turn signal switch	D-165	W
	R/S ISC	D-43	Water temp. sensor(1KR-FE engine)	D-30	
	RAD FAN relay	D-53	Water temp. sensor(K3-VE engine)	D-43	
	Radiator fan motor	D-53			
	Radio	D-221			
	Rear fog lamp	D-157			
	Rear intermittent relay	D-205			
	Rear oxygen sensor(1KR-FE engine)	D-30			
	Rear oxygen sensor(K3-VE engine)	D-42			
	Rear speaker	D-221			
	Rear speed sensor	D-61			
	Rear turn lamp	D-165			
	Rear view mirror switch	D-117			
	Rear washer motor(With INT system)	D-205			
	Rear washer motor(Without INT system)	D-209			
	Rear wiper motor(With INT system)	D-205			
	Rear wiper motor(Without INT system)	D-209			
	Rear wiper switch(With INT system)	D-205			
	Rear wiper switch(Without INT system)	D-209			
	S	Seatbelt switch	D-142		
Side airbag		D-86			
Side airbag sensor		D-85			
Side turn lamp		D-165			
Solenoid		D-69			
Speed sensor		D-142			

1-2 LHD VEHICLE

	ITEM	PAGE	ITEM	PAGE		
A	A/C evap. temp. sensor	D-245	Data link connector(Immobilizer)	D-113	D	
	A/C switch	D-245	Data link connector(Meter)	D-145		
	A/T ECU(A/T)	D-73	Defogger	D-129		
	A/T ECU(ABS)	D-66	Defogger switch	D-129		
	A/T ECU(Back up lamp)	D-193	Dome lamp	D-97		
	A/T ECU(Engine)[K3-VE engine]	D-50	Doorlock motor	D-105		
	A/T ECU(Meter)	D-145	Doorlock switch	D-106		
	ABS ECU(A/T)	D-74	Dual pressure switch	D-245		
	ABS ECU(ABS)	D-65	Duty solenoid	D-73		
	ABS ECU(Back up lamp)	D-193	EFI ECU(A/T)	D-74		E
	ABS ECU(Engine)[1KR-FE engine]	D-38	EFI ECU(ABS)	D-66		
	ABS ECU(Engine)[K3-VE engine]	D-50	EFI ECU(Back up lamp)	D-193		
	ABS ECU(Meter)	D-145	EFI ECU(Engine)[1KR-FE engine]	D-35		
	Airbag ECU	D-89	EFI ECU(Engine)[K3-VE engine]	D-47		
	Airbag squib	D-89	EFI ECU(Meter)	D-145		
	Alternator	D-25	EFI main relay(1KR-FE engine)	D-36		
	ANT	D-225	EFI main relay(K3-VE engine)	D-48		
Antenna coil	D-113	EPS ECU	D-81			
B	Back-up lamp	D-194	Flasher relay	D-169	F	
	Back-up lamp switch	D-194	Floor console illumination	D-185		
	Brake vacuum pressure switch	D-50	Fog lamp relay	D-161		
C	Cam position sensor(1KR-FE engine)	D-36	Fog lamp switch	D-161		
	Cam position sensor(K3-VE engine)	D-48	Front fog lamp	D-161		
	Cigarette lighter or Power outlet	D-239	Front oxygen sensor(1KR-FE engine)	D-36		
	Clearance lamp	D-185	Front oxygen sensor(K3-VE engine)	D-48		
	Courtesy switch	D-106	Front passenger seat belt warning	D-146		
	Crank angle sensor(1KR-FE engine)	D-36	Front satellite sensor	D-89		
	Crank angle sensor(K3-VE engine)	D-48	Front speaker	D-225		
Curtain shield airbag	D-90	Front speed sensor	D-65			
D	Data link connector(A/T)	D-73	Front turn lamp	D-169		
	Data link connector(ABS)	D-65	Front washer motor	D-201		
	Data link connector(Airbag)	D-89	Front wiper motor	D-201		
	Data link connector(Back up lamp)	D-193	Front wiper switch	D-201		
	Data link connector(DLC)	D-253	Fuel pump motor(1KR-FE engine)	D-36		
	Data link connector(Engine)[1KR-FE engine]	D-37	Fuel pump motor(K3-VE engine)	D-48		
	Data link connector(Engine)[K3-VE engine]	D-49	Fuel pump relay(1KR-FE engine)	D-36		
	Data link connector(EPS)	D-81	Fuel pump relay(K3-VE engine)	D-48		

	ITEM	PAGE	ITEM	PAGE		
F	Fuel sender gauge	D-145	Manifold absolute pressure/intake air temperature integrated type sensor	D-37	M	
H	Hazard switch	D-169				
	Headlamp	D-153	Map lamp	D-97		
	Headlamp leveling switch(Headlamp)	D-154	Master switch	D-137		
	Headlamp leveling switch (Tail & License plate lamp)	D-186	Meter	ABS	D-66	
	Headlamp leveling unit	D-154		Airbag	D-90	
	Headlamp relay	D-153		Brake	D-146	
	Headlamp switch	D-153		Buzzer(Back up lamp)	D-193	
	Heater blower motor	D-246		Buzzer(Meter)	D-145	
	Heater blower switch	D-246		Buzzer(Tail & License plate lamp)	D-186	
	Heater relay	D-245		Charge	D-25	
	Heater resistor	D-246		Door	D-106	
	High mounted stop lamp	D-177		Driver's seat belt	D-146	
	Horn	D-233		EPS	D-81	
	Horn relay	D-233		High beam	D-154	
	Horn switch	D-233		High-water temperature	D-146	
I	IG relay	D-9		Illumination	D-186	
	Ignition coil(1KR-FE engine)	D-35		LCD(A/T)	D-74	
	Ignition coil(K3-VE engine)	D-47		LCD(Back up lamp)	D-193	
	Ignition switch	D-8		LCD(Meter)	D-145	
	Immobilizer ECU	D-113		Low-water temperature	D-146	
	Injector(1KR-FE engine)	D-36		MIL(1KR-FE engine)	D-38	
	Injector(K3-VE engine)	D-49		MIL(K3-VE engine)	D-50	
	Intake air temp. sensor	D-49		O/D OFF	D-74	
	ITC ECU	D-105	Oil	D-146		
K	Key switch	D-145	Rear fog	D-161		
	Keyless entry sensor	D-105	Security	D-113		
	Knock sensor(1KR-FE engine)	D-36	SPEED	D-145		
	Knock sensor(K3-VE engine)	D-48	Turn	D-169		
L	License plate lamp	D-185	MGC relay	D-245		
	Linear throttle sensor(1KR-FE engine)	D-36	Mirror adjust	D-121		
	Linear throttle sensor(K3-VE engine)	D-49	Motor	D-81		
	LUC solenoid	D-73	Neutral start switch(A/T)	D-73	N	
	Luggage room lamp	D-97	Neutral start switch(Back up lamp)	D-194		
M	Magnet clutch	D-245	Noise filter(1KR-FE engine)	D-35		
			Noise filter(K3-VE engine)	D-48		
			O/D OFF switch	D-73	O	

	ITEM	PAGE	ITEM	PAGE			
O	Oil control valve(1KR-FE engine)	D-37	Starer	D-17	S		
	Oil control valve(K3-VE engine)	D-49	Starter relay	D-17			
	Oil fluid level switch	D-146	Stepper motor for ISC	D-37			
	Oil pressure switch	D-146	Stepper motor type EGR valve	D-37			
	Oil temperature sensor	D-73	Stop lamp	D-177			
P	Output revolution sensor	D-74	Stop lamp switch	D-177	T		
	Parking breke switch	D-146	Switch solenoid	D-73			
	Power window motor	D-137	Tachometer	D-145			
	Power window switch	D-137	Tail lamp	D-185			
	Pressure sensor	D-49	Tail lamp switch	D-185			
	Pretensioner	D-89	Torque sensor	D-81			
	Purge VSV(1KR-FE engine)	D-36	Turbine revolution sensor	D-74			
	Purge VSV(K3-VE engine)	D-49	Turn signal switch	D-169			
	R	R/S ISC	D-49	Water temp. sensor(1KR-FE engine)		D-36	W
		RAD FAN relay	D-57	Water temp. sensor(K3-VE engine)		D-49	
Radiator fan motor		D-57					
Radio		D-225					
Rear fog lamp		D-161					
Rear intermittent relay		D-213					
Rear oxygen sensor(1KR-FE engine)		D-36					
Rear oxygen sensor(K3-VE engine)		D-48					
Rear speaker		D-225					
Rear speed sensor		D-65					
Rear turn lamp		D-169					
Rear view mirror switch		D-121					
Rear washer motor(With INT system)		D-213					
Rear washer motor(Without INT system)		D-217					
Rear wiper motor(With INT system)		D-213					
Rear wiper motor(Without INT system)		D-217					
Rear wiper switch(With INT system)		D-213					
Rear wiper switch(Without INT system)		D-217					
S		Seatbelt switch	D-146				
		Side airbag	D-90				
		Side airbag sensor	D-89				
		Side turn lamp	D-169				
		Solenoid	D-73				
	Speed sensor	D-146					

TO INDEX

TO NEXT SECTION