

COLD START INJECTOR TIME SWITCH





COLD START INJECTOR TIME SWITCH INSPECTION

1. REMOVE COLD START INJECTOR TIME SWITCH 2. INSPECT COLD START INJECTOR TIME SWITCH

Using an ohmmeter, measure the resistance between each terminal.

Resistance:

STA – STJ

30 – 50Ωbelow 15° C (59°F)

70 – 90Ωabove 30° C (86° 9)

STA – Ground

30–90Ω

If the resistance is not as specified, replace the switch.

3. REINSTALL COLD START INJECTOR TIME SWITCH